

Contour Universal ArmSupport

Getting Started

Attach brackets

Turn the ArmSupport upside down on a flat surface. Loosely attach the brackets to the ArmSupport by using the thumb screw in the hole in the small arch in the bracket.



Slide the ArmSupport onto desk

Slide your ArmSupport with brackets attached onto your desktop. Adjust placement as needed by sliding thumb screws up and down the metal track. Tighten slightly.

