


# BakkerElkhuizen UltraBoard 950

## User Manual



### QWERTY



EN



FR



DE



NL




## The UltraBoard 950 in short

Thank you for purchasing the Ultraboard 950 Compact Keyboard. This space-saving keyboard is designed for Windows based PCs. We sincerely hope you will enjoy using the UltraBoard 950.


This quick-start guide will help you configure and use your new keyboard. Here are a few features of the UltraBoard 950:

- Space-saving compact design.
- Wired keyboard
- Connect peripheral devices via the 2 port USB hub.
- Scissor action keys with a finger friendly surface for high comfort and reduced tiredness when typing.
- Ultra-thin and height adjustable for enhanced comfort.
- 4 shortcut keys, Home, Mail, PrtScr and NumLock for fast working.
- Integrated multimedia keys.

 To extend the life of the UltraBoard 950, we recommend that you use the supplied case when you store your UltraBoard 950.

## Overview of the UltraBoard 950

- 1 Hotkeys
- 2 Status LEDs
- 3 Integrated NumLock keys
- 4 Multimedia keys
- 5 Height adjustable feet
- 6 USB Hub



## Getting started

1. Connect the Ultraboard Compact keyboard to your PC with the integrated USB plug.
2. This keyboard is "plug & play" so wait for a few seconds for your computer to detect the device and then you're free to start typing.  
**(Please note that the first time you connect your new keyboard, your operating system automatically installs the required driver. This process can take a few seconds.)**

## How to use the Fn key with the numpad and media keys

### Numpad

Ensuring NumLock is ON, hold the Fn key to activate the small light blue numbered keys for use.

### Multimedia keys

Function keys F7, F8, F9, F10, F11, F12 keys support Windows for multimedia use. Hold the Fn key and press F7 to F12 to use these functions.

### LED Indication



### LED \* (Green)

Power on - LED is green when keyboard is active

### LED 1 (Green)

NumLock - Solid when NumLock is active

### LED A (Green)

CapsLock - Solid when CapsLock is active

- |     |                |
|-----|----------------|
| F7  | Previous Track |
| F8  | Play/ Pause    |
| F9  | Next Track     |
| F10 | Mute           |
| F11 | Volume Down    |
| F12 | Volume Up      |





**Bakker  
Elkhuizen**

**BakkerElkhuizen**

Taalstraat 151  
5261 BC Vught  
Netherlands

tel. +31 36 546 7265  
email. [info@bakkerelkhuizen.com](mailto:info@bakkerelkhuizen.com)

*All rights reserved. All trade names are registered trademarks of the respective manufacturers listed. All specifications are subject to change without prior notice.*